


**INSTALLATION INSTRUCTIONS AND OWNER'S MANUAL** 



Product is supplied assembled. To separate Housing and Base, remove two #6-32 screws at top of housing and back out two #6-32 set screws on each side.

1. Route AC input wiring through wall gasket and base. Connect ground wire around one of the base mount screws. Insert gasket and mount base to standard j-box.

 Connect the AC input wires in fixture to supply with standard wire nuts. BROWN: LINE (120/ 277 VAC) BLUE: NEUTRAL GREEN: GROUND

3. Place Housing in position on Base. Tighten set screws on both sides, and #6-32 screws at top of housing, using light pressure. Apply firm hand pressure to top of Housing to compress gasket, then firmly tighten screws.

## **IMPORTANT SAFEGUARDS READ AND FOLLOW ALL SAFETY INSTRUCTIONS** 1. Disconnect AC power before servicing. 7. Mount and secure the fixture at a location and height 2. Refer to wiring diagram for proper connections. to avoid ready access and tampering by unauthorized 3. All servicing should be performed by qualified personnel. persons. 4. Consult your local building code for approved wiring and 8. The use of accessory equipment is not recommended by installation. the manufacturer and may cause an unsafe condition. 5. Do not use this equipment for other than intended use. 9. Suitable for wet locations. See product label for temperature 6. Do not let power cords touch hot surfaces. limitations. SAVE THESE INSTRUCTIONS

EELP, Inc. One Neshaminy Interplex Dr. Suite 300 Trevose, PA 19053 TEL:(800) 490-4496 www.eelp.net